



Installation can only be carried out by an authorized person and according to the mounting instructions. Any other installation is considered to be improper. For well installation and good luminaire work is necessary ensure a planarity of a mounting surface. Make sure that the luminaire is always disconnected from the power supply before the installation work. Do not use the luminaire if damaged or if damaged the power cable. Only damp microfiber cloth can be used for cleaning. Technical changes are subjected without notice. Do not dispose the luminaire or its parts as household waste, but make the proper recycling.

Table of maximal number of luminaires in one line					10A B	16A B	10A C	16A C
Length	Σlm	Σlm	Σlm	Σlm	Σ luminaires	Σ luminaires	Σ luminaires	Σ luminaires
1175	2600 lm				32	50	52	85
1175	3200 lm	4400 lm	6400 lm		10	16	16	26
1455	3250 lm	4000 lm	5500 lm	8000 lm	10	16	16	26


### Connection 1x3P




### Connection 2x5P SNS




### Connection 1x5P DALI




### Connection 2x5P SNS COR




### Connection 2x3P




### Connection 2x5P SNS, NM




### Connection 2x5P




### Connection 2x5P NM




### Connection 2x5P DALI



### Connection 2x7P DALI



### Connection 2x5P DALI NM



### Connection 2x7P DALI NM

